


#### **COMPONENTS**



N°	COMPONENTS	CODE
1	Quick-coupling textile backpack	02PIFRMH0001
2	Washer for sewing	
3	Quick-coupling washer for sewing	
4	Monofilament zipper #5	
5	Snap hook buckle	
6	Fastening 50 mm buckle with regulator	
7	Handy carrier	
8	Inner bag for water backpack	02PIFRMH0014
9	PVC filling mouth	
10	Quick-coupling discharge mouth	
11	Reinforcing washer with filter mouth	
12	HDPE cap for water packpack	04PTPLIN0023
13	Double effect nozzle	02PIFRMH0008
14	Nozzle holder	
15	Backpack discharge hose	02PIFRMH0020


### **MODE OF USE**

### **INNER BAG REMOVAL**





Unzip the back zipper.



- Remove the filter. - Unlock the filling mouth

and unscrew the internal

washer coupling, releasing

the bag from the backpack.



Remove the punctured bag through the back of the backpack.

# **BACKPACK**


**ASSEMBLY** 




Unzip the back zipper.



Place the bag inside.



Align the recesses of the backpack washer with the bag.




Place the filter on the washer.




Coil in the copper coupling with the inner washer of the bag and insert the washer without thread and the bag.




Zip the back zipper.



Retract the cap to enable coupling.





## **WASHING INSTRUCTIONS**

- Remove the hose, nozzle, and inner bag using the same change/replacement procedure as instructed in this manual.
- Remove the cap from the textile strap to which it is fixed by removing the stainless steel Phillips screw together with the washer.
- To avoid losing the screw, you can leave it in the cap once it has been removed.
- Wash the backpack by hand or in a washing machine.
- Remember: DO NOT SPIN-DRY
- The textile backpack can only be washed with the components sewn to it.
- After washing it, let it dry in the shade.
- When the backpack is clean and dry, place the cap on the textile strap by tightening the Phillips screw and the washer.
- Then, insert the bag.
- Fit the reinforcing washer with filter.
- Finally, coil the hose and the nozzle.

# **WARRANTY**

1-year warranty.

- The operating instructions must be followed to ensure the durability of the product and to avoid damage.
- Improper use of the water backpack, as well as any cleaning process other than those mentioned above, may alter the resistance levels of the product.

INFOREST SRL provides a warranty for manufacturing faults. Inforest SRL shall not be liable for incidental or consequential damages.



## **INFOREST ARGENTINA**

WWW.INFOREST.COM.AR ventas@inforest.com.ar comex@inforest.com.ar

inforest\_incendiosforestales f inforest.cba

Brasil 1238 Alta Gracia Córdoba - Argentina CP: 5186 Tel/Fax: +54 (0)3547- 430529 | 406693 CUIT 33-71411717-9

## **INFOREST IBÉRICA**

WWW.INFORESTIBERICA.COM info@inforestiberica.com



C Estaño 32, Campo Real Madrid España Tel: +34 681 31 46 46