




No	COMPONENTS	CÓDIGO
1	Textile backpack	02PIFRMH0002
2	Washer for riveting	04PTPLIN0004
3	Quick-coupling washer for sewing	04PTPLIN0007
4	Zipper	03MPTXCR0001
5	Snap hook buckle	03MPTXHE0025
6	Fastening buckle 50 mm	03MPTXHE0002
7	Radio holder	
8	Inner bag	02PIFRMH0028
9	Filling mouth	04PTPLIN0008
10	Discharge mouth	04PTPLIN0010
11	Discharge mouth plug	02PIFRMH0006
12	Reinforcement washer with filter	04PTPLIN0023
13	Cap	02PIFRMH0008
14	Double-effect nozzle	02PIFRMH0021
15	Nozzle holder	02PIFRMH0012

MODE OF USE

INNER BAG REMOVAL







Unzip the back zipper.

- Remove the filter. - - Unlock the filling and discharge mouth of the outer washer sockets by pushing them inwards.

Remove the punctured bag through the back of the backpack.


BACKPACK ASSEMBLY




Unzip the back zipper.



Place the bag inside.



Align the recesses of the backpack washer with the bag.




Place the filter on the washer.



Fit the ribbed area of the discharge mouth with the ribbed area of the lower washer of the backpack.



Tighten until there are no leaks.



WASHING INSTRUCTIONS

- Remove the hose, nozzle, and inner bag using the same change/replacement procedure as instructed in this manual.
- Remove the cap from the textile strap to which it is fixed by removing the stainless steel Phillips screw together with the washer.
- To avoid losing the screw, you can leave it in the cap once it has been removed.
- Wash the backpack by hand or in a washing machine.
- Remember: DO NOT SPIN-DRY
- The textile backpack can only be washed with the components sewn to it.
- After washing it, let it dry in the shade.
- When the backpack is clean and dry, place the cap on the textile strap by tightening the Phillips screw and the washer.
- Then, insert the bag.
- Fit the reinforcing washer with filter.
- Finally, coil the hose and the nozzle.

WARRANTY

1-year warranty.

- The operating instructions must be followed to ensure the durability of the product and to avoid damage.
- Improper use of the water backpack, as well as any cleaning process other than those mentioned above, may alter the resistance levels of the product.

INFOREST SRL provides a warranty for manufacturing faults. Inforest SRL shall not be liable for incidental or consequential damages.



INFOREST ARGENTINA

WWW.INFOREST.COM.AR ventas@inforest.com.ar comex@inforest.com.ar

inforest_incendiosforestales

f inforest.cba Brasil 1238 Alta Gracia

Córdoba - Argentina CP: 5186

CUIT 33-71411717-9

Tel/Fax: +54 (0)3547- 430529 | 406693

INFOREST IBÉRICA

WWW.INFORESTIBERICA.COM info@inforestiberica.com



Tel: +34 681 31 46 46

C Estaño 32, Campo Real Madrid España